

Sekusept® Cleaner Liquid cleaning agent

Concentrated liquid cleaning agent for manual cleaning of respiratory masks, respiratory protection equipment, diving apparatus and chemical protective suits before disinfection.



Sekusept® Cleaner is a cleaning agent for manual cleaning with cloth and sponge before disinfection in an immersion bath. For cleaning chemical protection suits, a brush can also be used.

Advantages

- Exceptional cleaning power
- Exceptional material compatibility
- User-friendly formula
- Efficient because of low usage concentration

APPLICATION INSTRUCTIONS

- Strictly observe the respective Dräger Instructions for Use for respiratory masks, respiratory protection equipment, chemical protective suits etc. as well as the application instructions of the product manufacturer!

DOSAGE

	Efficiency (%)	Concentration (ml/L)
Cleaning of respiratory protection devices and respiratory protection equipment in an immersion bath	0.5 - 1	5 - 10



D-98827-2013

Sekusept® Cleaner
Front side with measuring cup



D-98823-2013

Sekusept® Cleaner
Rear side

DOSING TABLE – LIQUID

Litre(s)	Concentration for use ¹⁾	
	0.5 %	1 %
1 litre	5 ml	10 ml
2 litres	10 ml	20 ml
3 litres	15 ml	30 ml
4 litres	20 ml	40 ml
5 litres	25 ml	50 ml
8 litres	40 ml	80 ml
10 litres	50 ml	100 ml
20 litres	100 ml	200 ml
30 litres	150 ml	300 ml

¹⁾ Observe concentration given in the respective Instructions for Use.

Application instructions:

Example: 10 litres = 1 % application solution = 100 ml of concentrated product + 9.9 litres of water.

Add concentrated product according to the water volume, stir briefly.

Solution can be used immediately. For normal contamination the solution can be used for one working day.

If the solution is visibly contaminated, please prepare new cleaning solution.

ORDERING INFORMATION

Sekusept® Cleaner 4 × 2 L bottle with measuring cup R 62 063

Separate product information can be requested from ECOLAB for usage as cleaning agent for medical products.
 Manufacturer: Sekusept® is a registered trademark of ECOLAB

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
 Moislinger Allee 53–55
 23558 Lübeck, Germany

www.draeger.com

SUBSIDIARIES**UNITED KINGDOM**

Draeger Safety UK Ltd.
 Blyth Riverside
 Business Park Blyth,
 Northumberland NE24 4RG
 Tel +44 1670 352 891
 Fax +44 1670 544 475



Ecolab Deutschland GmbH
 Ecolab-Allee 1
 40789 Monheim am Rhein
 Germany

EMERGENCY NUMBER:

England: 0870 600 6266

Phone: +49 (0) 2173-599-0